

**NOTES:**


1. Motor board, relays, circuit breaker, & transformer are located inside electric controller box.
2. Motor must rotate counter clockwise from viewpoint for filters that contain a screen with area less than 5.0 sq. ft. (I.E. models LPF2-SP, 2-XLP, 3-LP, 3-SP, 4-LPE, 4-P & 6-P). Motor must rotate clockwise for all other filters.

UNLESS OTHERWISE SPECIFIED  
 DIMENSIONS ARE IN INCHES  
 TOLERANCES

DECIMALS	ANGULAR
.XX ± .05	± 0.5 DEG.
.XXX ± .01	

**AUTOMATIC FILTERS, INC.**  
 2672 S. LA CIENEGA BLVD.  
 LOS ANGELES, CA 90034  
 (310) 839-2828 FAX (310) 839-6878

TITLE **WIRING LAYOUT FOR LPF  
 FILTER WITH GB6 CONTROLLER,  
 ELECTRIC FLUSH VALVE, &  
 SOLENOID VENT FOR PISTON**



DRAWN	DATE
S. PERKINSON	03/29/12
CHECKED	
DESIGN FOR:	

SIZE	DWG NO.	REV
A	WIRE-LPFG6-EFV-SOL-LAY-01	N/A
Not To Scale		SHEET 1 OF 1