



REVISIONS				
REV	ZONE	DESCRIPTION	DATE	APPROVED
01	ALL	MOUNTED SOLENOID DIRECTLY TO PISTON	01/26/18	R. LAM

See Note 2.

NOTES:

1. Motor board, relays, circuit breaker, & transformer are located inside electric controller box. See connection drawing for detailed wiring of components to controller.
2. Motor must rotate counter clockwise from viewpoint for filters that contain a screen with area less than 5.0 sq. ft. (I.E. models LPF2-SP, 2-XLP, 3-LP, 3-SP, 4-LPE, 4-P & 6-P). Motor must rotate clockwise for all other filters.

Wire Hydraulic Tube

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES		AUTOMATIC FILTERS, INC. 2672 S. LA CIENEGA BLVD. LOS ANGELES, CA 90034 (310) 839-2828 FAX (310) 839-6878		
DECIMALS .XX ± .05 .XXX ± .01	ANGULAR ± 0.5 DEG.	TITLE LAYOUT FOR LPF FILTER WITH GB6 CONTROLLER, ELECTRIC FLUSH VALVE, SOLENOID VENT FOR PISTON, & DEWATERING SYSTEM		
DRAWN J. KAWAMOTO	DATE 04/16/13	SIZE A	DWG NO. WIRE-LPFGB6-EFV-LAY-03	REV 01
DESIGN FOR:		Not To Scale		SHEET 1 OF 1